

## **Oil Pressure Sensor – 2009-2016 3.5L Chevrolet Impala**

### **Required Tools**

- Socket Wrench
- 1 1/16 inch (27mm) socket
- 10 Inch Extension
- Torque Wrench

### **General Repair Steps**

1. Locate the Oil Pressure Sensor on the passenger side of the vehicle, behind the Exhaust Manifold and near the Oil Filter.
2. From underneath the car, disconnect the Oil Pressure Sensor connector.
3. Using the 1 1/16 inch socket and 10 inch extension, remove the Oil Pressure Sensor.
4. Ensure the old O-ring was fully removed, and that the new Oil Pressure Sensor has an O-ring installed.
5. Thread in the new Oil Pressure sensor by hand.
6. Torque the Oil Pressure Sensor to 12 foot pounds.
7. Plug in the Oil Pressure Sensor connector.